Disclaimer

This is strictly my personal documentation for the wiring modifications I did on my 1993 Mazda RX7 from January 2010 – December 2012. This is not a tutorial. These modifications are mostly NOT NEEDED for the average LS1 swap. Expert knowledge of the factory wiring manual is REQUIRED to follow this document. I am not responsible for any damage that these diagrams may produce to your car or yourself.

Any modifications you see in this document should be thoroughly understood before you attempt to re-create what I have done. Specifically the connectors I added to the various harnesses throughout the RX7's chassis; X-00, X-25, X-26, X-27, and Z-01 through Z-13. All of these connections have been designed, named, and added by me and must be considered when planning your own modifications based on this document.

Notes:

This document is organized as follows:

- Explanation of what factory parts / connectors I've deleted with my modifications
- Explanation of electrical features I've lost and features I've gained.
- Factory diagrams annotated by me to show modifications.
- Documents covering each new connector and the LS1 harness in detail.
- Hand drawn diagrams covering new circuits integrated into existing harnesses.

Wire colors mentioned throughout this document may not be 100% accurate but the pin / connector positions should be 100%. I always recommend using a continuity meter when in doubt.

I made the mistake of labeling new connectors Z-01 through Z-13. These connectors could also be confused with page numbers in the factory wiring manual. However, if I say "see Z-13 for more details" I'm referring to the documents that come after the factory diagrams in the file that cover the extra connectors in detail and NOT page 13 of the factory wiring manual.

Explicit details about my alarm wiring, placement, and consequently full documentation on connector Z-01 is not included in this file for obvious reasons :)

My build thread can be seen at http://www.norotors.com/index.php?topic=70.0

I do not offer support for this document but welcome corrections. I can be reached under the username halfspec on norotors.com or by email at <u>halfspec@gmail.com</u>

Thanks / Credit:

Danzan for your stickies on v8rx7forum.com and norotors.com which jumpstarted this process
Pez for your help over PM, email, and phone + your A/C diagram.
digitalsolo for hosting norotors.com and hosting this file :)
SemiSouth Labs for laying off 90+ employees and giving me the 60+ hours it took to put this document together (something that would have otherwise probably never happened).

Electrical parts removed:

120A MAIN Fuse, connector, and Wiring *A/C Relay *A/C Pressure Switch Air Bag Air Bag Harness and ALL 10 connectors Air Bag Impact Sensors Air Bag Diagnostic Module Air Pump Relay Bose Speaker + Enclosures / Waveguide **Clockspring and *Steering Wheel** Cruise Control steering wheel switch **Cruise Control Gauge Cluster switch Circuit Opening Relay** Condenser **Center Speaker Amplifier Center Speaker Cruise Control Unit Cruise Control Actuator** *Door Lock Timer Unit *ECU EGI MAIN Relay EL Unit **Emission Harness Engine Harness Exhaust Heat Warning Sensor** *Fan Relays 1-4 *Fuel Pump Relay Front Relay Box Front Windshield Washer Motor **Fuel Pump Resistor** Head Unit *Gauge Cluster *Horns *Horn Relay **Option Switch Radio Relay** *Rear Defroster Relay **Rear Washer Motor** Rear Wiper Motor + Arm. Starter Cut Relay ***TNS Relay**

* = Item was replaced or relocated with a newer or an updated version that supports the LS1 engine swap.

Electrical connectors removed:

A1-03 -> Starter Cut Relay Connector B1-20 -> EL Unit Connector + Wiring B1-01 -> ECU Connector + Wiring B1-02 -> EGI Main Relay Connector + Wiring B1-03 -> Circuit Opening Relay Connector + Wiring B1-04 -> Fuel Pump Relay Connector + Wiring B1-05 -> Fuel Pump Resistor Connector + Wiring B1-05 -> A/P Relay Connector + Wiring B1-09 -> Igniter Connector + Wiring B1-10 -> Condenser Connector + Wiring B1-45 -> Pressure Sensor Connector + Wiring B1-52 -> Clutch Switch Connector + Wiring B2-01 -> Cooling Fan Relay No. 1 Connector + Wiring B2-02 -> Cooling Fan Relay No. 2 Connector + Wiring B2-03 -> Cooling Fan Relay No. 3 Connector + Wiring B2-04 -> Cooling Fan Relay No. 4 Connector + Wiring B2-05 -> Cooling Fan Motor No. 1 Connector + Wiring B2-06 -> Cooling Fan Motor No. 2 Connector + Wiring C1-01 -> Instrument Cluster Connectors + Wiring C1-02 -> Exhaust Heat Warning Sensor Connector + Wiring D1-02 -> Front Windshield Washer Motor Connector + Wiring D1-01 -> Rear Wiper motor connector + Wiring D2-02 -> Rear Washer motor connector + Wiring E1-06 -> LH Headlight Connector E1-07 -> RH Headlight Connector E1-02 -> RETRACTABLE headlight relay connector E3-09 -> TNS Relay Connector E1-05 -> Headlight Relay Connector F3-03 -> Horn Relay Connector + Wiring. F3-04 -> Horn Switch Connector F3-05 -> LH Horn Connector + Wiring F3-06 -> RH Horn Connector + Wiring G-03 -> AC Relay Connector + Wiring G-04 -> A/C Pressure Switch + Wiring I1-01 - Rear Defroster Relay Connector J2-01 -> Audio Unit Connector J2-04 -> Acoustic Wave Guide Assembly connector + Wiring J2-05 -> Radio Relay Connector + Wiring J2-07 -> Center Speaker Connector J2-06 -> Center Speaker Amplifier Connector + Wiring J2-08 -> Audio Ground Harness Connector + Wiring J4-04 -> Option Switch Connector + Wiring K2-01 -> Door Lock Timer Unit Connector Q-01 -> Cruise Control Unit Connector + Wiring Q-02 -> Cruise Control Main Switch Connector + Wiring Q-04 -> Cruise Control Actuator Connector + Wiring Q-05 -> Cruise Control Steering Wheel Switch Connector + Wiring U-01 -> Diagnosis Connector + Wiring. *X-01 -> Main Fuse Box *X-02 -> Relay Fuse Box X-05 -> Connector between Front and Emission harnesses X-09 -> Connector between Front and Air Bag harnesses X-11 -> Connector between Front and Engine harnesses X-12 -> Connector between Front and Engine harnesses X-14 -> Connector between Emission and Dash harnesses **X-15 -> Connector between Instrument and Hash harnesses **X-16 -> Connector between Instrument and Dash harnesses X-18 -> Connector between Instrument and Instrument #2 harnesses * = Item was replaced or relocated with a newer or an updated version that supports the LS1 engine swap.

** = Cannot be removed without merging some wires to X-17. See X connector index for details.

Features Lost:

Air Bags A quiet fuel pump Bose Speaker System Center Speaker *Cruise Control Driver's side control of passenger door lock Rear Wiper Windshield Washers

* Adding a stock Camaro cruise control module is an option and is supported by my wiring.

Features Gained:

Programmable Gauge Cluster with Shift and Idiot Lights. Programmable Dash-top Auxiliary Gauge Pod Racelogic Traction Control LS1 PCM Controlled Dual Stage Fan Control LS1 PCM controlled A/C Compressor Control Integrated Viper 5901 2way Alarm. Remote Door Lock/Unlock Remote Trunk Release HID Lighting Louder/Manlier Horns Integrated AEM UEGO Wideband with built in HPtuners connection Consolidated Engine Bay Fuse Box Centrally Relocated Battery Switched 12V Auxiliary Connector Located by Dome Light A Fully Documented Wiring Manual :)

Mazda RX-7

1993 Wiring Diagram



+ LS1 Wiring Modifications by Halfspec



SYSTEM INDEX

ENGINE-RELATED SYSTEMS

STARTING SYSTEM	
MT	Z-24
EC-AT	Z-26
CHARGING SYSTEM	
MT	Z-24
EC-AT	Z-26
ENGINE CONTROL SYSTEM	Z-28
FUEL CONTROL SYSTEM	Z-28
IGNITION SYSTEM	Z-28
COOLING FAN SYSTEM	Z-42

CHASSIS-RELATED SYSTEMS

EC-AT CONTROL SYSTEM Z	-70
SHIFT-LOCK SYSTEM Z	-76
4 WHEEL ANTILOCK BRAKE	
SYSTEM (4WABS) Z-	102

INSTRUMENT CLUSTER-RELATED SYSTEMS

INSTRUMENT CLUSTER &

WARNING LAMPS

MT	Z-44
EC-AT Z-44,	Z-48
SELECTOR INDICATOR LAMPS	Z-48

BODY-RELATED SYSTEMS

WINDSHIELD WIPER & WASHER	Z-50
REAR WIPER & WASHER	Z-52
HEADLIGHT CLEANER	Z-54
HORNS	Z-66
KEY INTERLOCK SYSTEM	Z-76
REAR WINDOW DEFROSTER	Z-78
CENTRAL PROCESSING UNIT (CPU)	Z-90
THEFT-DETERRENT	

INTERIOR LIGHTING SYSTEMS

ILLUMINATION LAMPS	Z-80
INTERIOR LAMP	Z-82
CARGO COMPARTMENT LAMP	Z-82
INGITION KEY ILLUMINATION	Z-82
GLOVE BOX LAMP	Z-82

EXTERIOR LIGHTING SYSTEMS

RETRACTABLE HEADLIGHT

SYSTEM	Z-56
HEADLIGHTS	Z-56
FRONT FOG LIGHTS	Z-56
DAYTIME RUNNING LIGHT (DRL)	
CONTROL SYSTEM	Z-58
PARKING LIGHTS	Z-60
FRONT SIDE MARKER LIGHTS	Z-60
TAILLIGHTS	Z-60
REAR SIDE MARKER LIGHTS	Z-60
LICENSE PLATE LIGHTS	Z-60
TURN & HAZARD WARNING LIGHTS	
FEDERAL/CALIFORNIA	Z-62
CANADA	Z-64
STOPLIGHTS	Z-66
HIGH-MOUNT STOPLIGHT	Z-66
BACK-UP LIGHTS	Z-66
DOOR KEY ILLUMINATION	Z-82

AIR CONDITIONING-RELATED SYSTEMS

HEATER	Z-68
AIR CONDITIONER	Z-68

ACCESSORIES

CIGARETTE LIGHTER	Z-78
AUDIO SYSTEM TYPE-1	Z-84
AUDIO SYSTEM TYPE-2	
(BOSE ACOUSTIC WAVE®	
MUSIC SYSTEM)	Z-86
POWER ANTENNA	Z-88

CONTROL SYSTEM	. Z-90
POWER WINDOW	Z-94
POWER DOOR LOCK	Z-96
POWER OUTSIDE MIRROR	Z-98
SLIDING SUNROOF	Z-100
CRUISE CONTROL SYSTEM	Z-104
AIR BAG SYSTEM	Z-110

OTHERS DIAGNOSIS CONNECTOR...... Z-112

GI

1993 Mazda **RX-7** Wiring Diagram

CONTENTS

GENERAL INFORMATION

GROUND POINTS

ELECTRICAL WIRING SCHEMATIC



FOREWORD

This wiring diagram incorporates the wiring schematics of the basic vehicle and available optional equipment. Actual vehicle wiring may vary slightly depending on optional equipment or local specifications, or both. All information in this booklet is based on information available at the time of printing. Mazda Motor Corporation reserves the right to make changes without previous notice.

SYSTEM CIRCUIT A∼U DIAGRAM/ CONNECTOR LOCATIONS

COMMON CONNECTORS



JB

JOINT BOX COMPLETE WIRING SYSTEM





Mazda Motor Corporation HIROSHIMA, JAPAN

APPLICATION: This manual applies to vehicles beginning with he Vehicle Identification Numbers (VIN) on the ollowing page.

© 1991 Mazda Motor Corporation PRINTED IN JAPAN, DEC. '91 10 5210-10-91H



GENERAL INFORMATION

Wiring Diagrams

Contents of wiring diagrams	GI-2
Using wiring diagrams	GI-2

Reading Wiring Diagrams

Ground points	GI-3
System circuit diagram/connector diagram	GI-4
Routing diagram	GI-6
Harness symbols	GI-7
Symbols	GI-8
Logic symbols	GI-10
Abbreviations used in this booklet	GI-10

Troubleshooting

Precautions to take when servicing an electrical system	GI-11
Handling connectors	GI-12
Using electrical measuring equipment	GI-13
Measuring voltage	GI-14
Measuring continuity/resistance	GI-15
Finding short circuits	GI-16



VEHICLE IDENTIFICATION NUMBERS (VIN) (CHASSIS NUMBER)

JM1 FD332* P0 200001~ CANADA

JM1 FD331* P0 200001~ FEDERAL & CALIFORNIA

*

Color	Code	Color	Code
Blue	L	Natural	N
Black	В	Orange	0
Brown	BR	Pink	ρ
Dark Blue	DL	Red	R
Dark Green	DG	Purple	PU
Green	G	Tan	T
Gray	GY	White	W
Light Blue	LB	Yellow	Y
Light Green	LG	Violet	V

Contents of wiring diagrams

 This document comprises the 8 groups shown below. The main components are summarized in the components location diagram at the end of the document.



Using wiring diagrams

7-2

. The use of the wiring diagram depends on its application.



	wingt with		open to electrical writig achematic.
For checking ground circuit of individual systems	Open to page with ground point diagram and fold out common connector diagram or joint box diagram.	For finding page numbers of systems and components	Parts Index System Index

Ground points



This shows ground points of the harness.

Z-GI-3

Z-3



diagrams correspond to those in the ground point diagram.

System circuit diagram/connector diagram

 These show the circuits for each system, from the power supply to the ground. The power supply side is on the upper part of the page, the ground side on the lower part. The diagrams describe circuits with the ignition switch off.

Below is an explanation of the various points in the diagram.



Reading Wiring Diagrams



Z-GI-6

7-6

Routing diagram

- . The routing diagram shows where electrical components are on the system circuit diagram by call out line and connector symbols.
- · Specified values are listed beside the routing diagram or on the following page.



			THE RADE STORES	0.0	
			ente LAdram warrit agli	8-11	
			Permanen angeret apresed phillips search seat	88-14	
		-	Der eine allere	8-844	
80	0	Particle creater	Spinist select. On	Approx 180	
12.1		100	Appendix 1.70		
*	0	Service service Density at Vice-measurement	(ve 301' C. (Mil' Y)	Agent 224	
342	0	-marge	Regime explains temperature 30°C ddf #1	Appendix 13.1	
_		nereaster /	Atter watth cal	Augurent Hi alle	

whether an electrical component is good.

Reading Wiring Diagrams

Harness symbols

DESCRIPTION OF HARNESS	COLOR	SYMBOL	DESCRIPTION OF HARNESS	SYMBOL
FRONT HARNESS		(F)	REAR HARNESS	(R)
ENGINE HARNESS		(E)	REAR NO. 2 HARNESS	(R2)
DASH HARNESS		(D)	REAR NO. 3 HARNESS	(R3)
INSTRUMENT PANEL HARNESS		(1)	FLOOR HARNESS	(FR)
EMISSION HARNESS		(EM)	DOOR NO. 1 HARNESS	(DR1)
A/C HARNESS		(AC)	DOOR NO. 2 HARNESS	(DR2)
INTERIOR LAMP HARNESS		(IN)	AIR BAG HARNESS	(AB)



Z-GI-8

Z-8

Reading Wiring Diagrams

Symbols

Symbol	Meaning	Symbol		N	leanin	g	
Battery	 Generates electricity through chemical reaction. Supplies direct current to circuits. 	Resistance	A resi Mainly compo maint Readi	stor with y used to onents aining r ng resis	th a con to prote in circu rated vo stance	nstant v ect elec uits by oltage. values.	value. trical
Ground (1)	 Connecting point to vehicle body or other ground wire where current flows from positive to negative terminal of battery. Ground (1) indicates a ground point to body through wire harness. Ground (2) indicates point where component is grounded directly to body. Remarks Current will not flow through a 		< Colore Narrow- Color Black Brown	No. 1 Resistant	No No No No No No No No No No No No No N	Vide No. 3 Multiplier × 10° × 101	No. 4
	circuit if ground is faulty.		Red	2	2	× 10 ²	
Fuse (1)	Melts when current flow exceeds		Yellow	4	4	× 104	-
	current flow.		Green	5	5	× 105	-
-2-0-			Blue	6	6	× 10 ⁴	
	Precautions		Purple	7	7	× 107	
(box)	 Do not replace with fuses exceeding specified capacity. 		Grev	8	8	× 10 ⁸	
Fuse (2)	< Blade type > < Tube type >		White	9	9	× 10 ⁹	
\frown			Gold			× 10-1	±5%
teros		,	Silver			× 10-7	±10%
(Cartridge)	L'HE OF		-				±20%
Main fuse/ Fusible link	<cartridge type=""> <fusible link=""></fusible></cartridge>		<numer< td=""><td>32 Seco First</td><td>Third:</td><td>× 10^x sistance</td><td>value:</td></numer<>	32 Seco First	Third:	× 10 ^x sistance	value:
Transistor (1) Collector (C) Base NPN (B) NPN Emitter (E)	 Electrical switching component. Turns on when voltage is applied to the base (B). Collector indication mark 	Motor	• Conve mecha	rts elec inical e	trical e nergy.	energy i	nto
Transistor (2) Collector (C) Base PNP (B) PNP Emitter (E)	• Reading code. • Reading code. 2 S C 828 A Semiconductor Number of terminals • Revision mark A: High-frequency PNP C: High-frequency NPN D: Low-frequency NPN	Pump	• Pulls i liquids	n and d	lischar	ges gas	es and
Lamp	 Emits light and generates heat when current flows through filament. 	Cigarette lighter	• Electri	cal coil	that g	enerate	s heat

Reading Wiring Diagrams

Symbol	Meaning	Symbol	Meaning
Horn	 Generates sound when current flows. 	Switch (1)	 Allows or breaks current flow by opening and closing circuits.
Speaker		Switch (2)	
Heater	Generates heat when current flows.	Harness	Unconnected intersecting harness
Speed sensor	 Movement of magnet in speedometer turns contact within sensor on and off. 	(Not connected)	Connected Intersecting harness.
Ignition switch	 Turning ignition key switches circuit to operate various component. 	(Connected)	
Relay (1)	 Current flowing through coil produce 	s electromagnetic f	force causing contact to open or close
3 %		No current to coi	Current to coil
Normally open (NO)	Normally open relay (NO)	3/ × No 1	flow Is
formally closed (NC)	Normally closed relay (NC)	Flow	No flow
Sensor (variable)	 Resistance changes with other components operation. 	Diode —— I4	 Known as a semiconductor rectifier, the diode allows current flow in one direction only. Cathode (K) H Anode (A) — Flow of electric current

Sensor (thermistor)	 Resistance changes with temperature. 	Light-emitting diode (LED)	 A diode that lights when current flows. Unlike ordinary bulbs, the diode does not generate heat when lit. Cathode (K) - Anode (A)
Capacitor	 Component that temporarily stores electrical charge. 		Flow of current
		Reference diode (Zener diode)	 Allows current to flow in one direction up to a certain voltage;
Solenoid	 Current flowing through coll generates electromagnetic force to operate plungers. 	M	allows current to flow in the other direction once that voltage is exceeded.

Z-9

Z-GI-9

Z-GI-10

Reading Wiring Diagrams

Logic symbols

Types of logic symbols	Operation	Expressing output	Simple relay circuits
OR AC	Input to A or B will produce output at C.	Low electrical potential (L) at A and B→no output (L) at C High electrical potential (H) at A or B→output (H) at C	
	Input to A and B will produce output at C.	High electrical potential (H) at A and B→output (H) at C Low electrical potential (L) at A or B→no output (L) at C	A B C
INV	No input to A will produce an output at B. An input to A will not produce an output at B.	Low electrical potential (L) at A→no ground (H) B High electrical potential (H) at A→grounds (L) B	А
PROCESS	Simplified representation describes main function. 1. Signal detector for en tachometer. 2. Signal converter for tu unit.	n of complex functions within circuit gine control unit, cooling unit, and arn and hazard flasher unit and igniter	(Examples) Igniters Signal converter Coll signal converted to ON/OFF signal

Abbreviations used in this booklet

A	Ampere	ECPS	Ele
AAS	Autoadjusting Suspension		Ste
ABS	Antilock Brake System	ECU	En
ACC	Accessory	EGI	Ele
ACCEL	Accelerator	EGR	Ex
ACV	Air Control Valve	ELEC	Ele
ADD	Additional	ELR	Em
AE	Acoustic Equilibration	ETR	Ele
AIS	Air Injection System	EXH	Ext
ALL	Automatic Load Leveling	F	Fro
ALT	Alternator	FICB	Fat
AM	Amplitude Modulation	FM	Fre
AMP	Amplifier	F/8	Fee
ANT	Antenna	F/I	Fu
AS	Autostop	GEN	Get
ASV	Air Supply Valve	HEAT	He
AT	Automatic transmission	HEI	Hip
ATP	Atmospheric Pressure	HI	Hig

ECPS	Electronically Controlled Power
ECH	Steering Engine Control Linit
200	Engine Control Onit
EGI	Electronic Gasoline Injection
EGR	Exhaust Gas Recirculation
ELEC	Electric
ELR	Emergency Locking Retractor
ETR	Electronic Tuner
EXH	Exhaust
F	Front
FICB	Fast-Idle Cam Breaker
FM	Frequency Modulation
F/8	Feedback
F/1	Fuel Injector
GEN	Generator
HEAT	Heater
HEI	High-Energy Ignition

MW	Middle Wave
NC	Normally Closed
NO	Normally Open
OD	Overdrive
ALC: 1887 ALC: 1	100 1 (100 - 10 (100 a) a)

- OFF Switch Off
- ON Switch On p
 - Power
- PACV Pressure Regulator Control Solenoid Valve
- PRG Purge Solenoid Valve
- PTC **Positive Temperature Coefficient**
 - Heater
- P/S **Power Steering**
- QSS **Quick-Start System**
- R Rear
- REC Recirculation RF **Right Front**

16

Right Hand RH

MIP.	Annospheric Pressure
ATX	Automatic Transaxle
A/C	Air Conditioner
A/F	Air Fuel
A/R	Auto Reverse
B	Battery
BAC	Bypass Air Control Valve
B/L	Bilevel
CARB	Carburetor
CCT	Circuit
CIGAR	Cigarette
COMBI	Combination
CON	Conditioner
CONT	Control
CPU	Central Processing Unit
CSD	Cold Start Device
DEF	Defroster
DOHC	Double-Overhead Camshaft
EC-ET	Electronic Controlled Automatic
100000000000000000000000000000000000000	Transmission
	Electrically Control Automatic
	Transaxle

7-10

5.0075	Ulah France Instition
PHEI	high-energy ignition
HI	High
H/D	Heater/Defroster
IG	Ignition
ILLUMI	Illumination
INT	Intermittent
ISC	Idle-Speed Control
JB	Joint Box
LCD	Liquid Crystal Display
LF	Left Front
LH	Left Hand
LO	Low
LR	Left Rear
LW	Low Wave
M	Motor
MID	Middle
MIL	Malfunction Indicator Lamp
MIN	Minute
MEX	Mixture
MPX	Multiplex
MT	Manual Transmission
MTR	Mechanical Tuning Radio
MTX	Manual Transaxle

RPM	Revolutions Per Minute
RH	Right Rear
SOL	Solenoid
ST	Start
SW	Switch
TCV	Twin Scroll Turbocharger
	Solenoid Valve
TEMP	Temperature
TICS	Triple Induction Control System
TR	Transistor
TWS	Total Wiring System
V	Volt
VENT	Ventilation
VOL	Volume
VRIS	Variable Resonance Induction
	System
W	Watt(s)

Precautions to take when servicing an electrical system

- Note the following items when servicing the electrical system.
- Do not alter the wiring or electrical equipment in any way; this may damage the vehicle or cause a fire from short-circuiting a circuit or overloading it.
- The negative (-) battery cable must be removed first and installed last.



Caution

 Be sure that the ignition and other switches are off before disconnecting or connecting the battery cables.

Failure to do so may damage the semiconductor components.

Secure harnesses with provided clamps to take up slack.

Caution

capacity.

 Replacing a fuse with one of a larger capacity than designated may damage components or cause a fire.

Do not replace with fuses exceeding specified

 Tape areas of the harness that may rub or bump against sharp edges to protect it from damage.

10 A

 When mounting components, be sure the harness is not caught or damaged.

15A





Caution

- Clamp all harnesses near vibrating components (for example, the engine) to remove slack and to prevent contact resulting from vibration.
- · Do not handle electrical components roughly or drop
- Disconnect heatsensitive parts (for example, relays and ECU) when performing maintenance (such as
- Make sure that the connectors are securely connected when installed.

them.





Z-11

Handling connectors

Caution

· Be sure to grasp the connectors, not the wires, when disconnecting them.

Co	nnector removal	Checking connector contacts	Checking for loose terminals	Replacing terminal
	Remove	Caution Improperty engaged connectors will cause poor terminal contact.	Caution A loose terminal will cause poor terminal contact.	<cpu connector=""> Raise the rear cover. Lift the tab with a thin piece of metal and remove the terminal. </cpu>
Push type			The second	<general connector=""> Lift the tab with a thin piece of metal and remove the terminal.</general>
		When using a matching male terminal, make sure there is no looseness in the female terminal.	Make sure the terminals are not pushed out of the connector when engaged.	<round connectors=""> 1. Raise the cover. 2. Lift the terminal</round>
				to remove it. 3. Make sure the terminal is securely mounted in the connector when installing.
ed			Pull lightly on individual wires to check that they are secured in the terminal.	<common connectors="" ground=""></common>



Z-12

Using electrical measuring equipment

Equipment	Use	Operation	Handling precautions
Test lamp	Test to find open or shorted circuits.	 Connect the test lamp between the circuit being measured and a ground. The lamp will light if the circuit is energized to the point tested. 	 Test lamps use 12V 1.4W or 3.4W bulbs or light-emitting diodes (LEDs). Using a large-capacity bulb may damage the CPU.
Jumper wire	Used to create a temporary circuit.	• Connect the jumper wire between the terminals of a circuit to bypass a switch.	 Do not connect the jumper wire from the power source line to a ground; this may cause burning or other damage to harnesses or electronic components.
Voltmeter	Used for measuring the voltage of a circuit to locate possible opens or shorts.	 Connect the positive (+) probe to the point where voltage is to be measured and the negative (-) probe to a ground. 	 Connect the voltmeter in parallel with the circuit. Set the range to the desired voltage. Use the service hole when measuring the voltage at the diagnosis connector. Tie a thin wire to the positive (+) probe to access narrow terminals.
Ohmmeter	Used to find opens and shorts in the circuit, to confirm continuity and to measure resistance.	 Zero the ohmmeter. Using that voltage is not applied to the circuit. Connect the probes between two points in a circuit. 	 Zero the meter after switching to the measuring range. Before using the ohmmeter, make sure the ignition switch is off or the negative (-) battery cable is disconnected to prevent burning or otherwise damaging the ohmmeter.
Ammeter	Used to check alternator output, current supplied to the starter, and dark current within a circuit. Note Dark current is the constant flow of current while the ignition switch is OFF.	 Connect the ammeter in series with the circuit by touching the positive (+) probe to the power-side terminal and the negative (-) probe to the ground-side terminal. 	 Set the range to the desired amperage. Connect the ammeter in series with the circuit. The ammeter may be burned or otherwise damaged if it is connected in parallel.

Z-GI-14

Troubleshooting

Measuring voltage







Measuring voltage of ground unit

Z-14

Touch the voltmeter probe to the ground wire when checking the ground circuit.



Measuring continuity/resistance



Checking diodes

Continuity is checked according to the direction of the positive (+) and negative (-) probes of the ohmmeter in the circuit containing the diode.



Note

The negative (-) probe of the ohmmeter is connected to the positive terminal of the internal ohmmeter battery, the positive (+) probe to the negative terminal of the battery.



Checking sensors and solenoid valves



Connect the ohmmeter probes to the sensor or solenoid valve terminals to check resistance.

Caution

Verify the operating state of the sensor before checking resistance because readings vary accordingly.

Checking condensers



- 1. Short between the terminals with a jumper wire to discharge the capacitor.
- 2. Set the ohmmeter range to $\times 10 k\Omega$ and connect it to the capacitor terminals.
- 3. The capacitor is good if the needle of the ohmmeter swings once and returns to its original position.

Finding short circuits

Shorts occur between the power (positive) and ground (negative) sides of a circuit. Therefore, finding a short circuit requires determining how the circuit is routed.



Circuits not connected to control unit

Circuits connected to control unit

		Examples	Findles shad should
	Short location	Symptom	Pinding short circuit
Fuse Short (A)	Short (A)	• Fuse melts.	 Remove the fuse and main fuse of the circuit. Disconnect all connectors of electrical components in the circuit. Attach a voltmeter or test lamp to the fuse box and
Solenold (A) Short Short (C)	Short (B)	 Solenoid A operates when the ignition switch is ON. 	Test lamp CHUID 4. Check the voltmeter reading or test lamp as the connectors are connected.
	Short (C)	 The CPU transistor burns out when the ignition switch is turned ON. 	A short has occurred where the voltmeter reading changes or the test lamp comes on.
Switch	Short (D)	 The CPU thinks the switch is ON because the same condi- tions exist as when the switch is ON. 	Sensor/switch CPU CPU CPU CPU 1. Attach the test lamp or voltmeter to the CPU connector. 2. Connect to the switch/ sensor connector.
	Short (E)	 The CPU senses the sensor to be 0Ω because the same conditions exist as when the resistance value is 0Ω. The CPU equipped with the self-diagnosis function out- puts the code. 	A short has occurred where the voltmeter reads 0V or the test lamp goes out.



-





SYSTEM CIRCUIT DIAGRAM/ CONNECTOR LOCATIONS

ENGINE-RELATED SYSTEMS

STARTING SYSTEM

MT	Z-24
EC-AT	Z-26
CHARGING SYSTEM	
MT	Z-24
EC-AT	Z-26
ENGINE CONTROL SYSTEM	Z-28
FUEL CONTROL SYSTEM	Z-28
IGNITION SYSTEM	Z-28
COOLING FAN SYSTEM	Z-42

CHASSIS-RELATED SYSTEMS

C-AT CONTROL SYSTEM	Z-70
HIFT-LOCK SYSTEM	Z-76
WHEEL ANTILOCK BRAKE	
YSTEM (4WABS)	Z-102

INSTRUMENT CLUSTER-RELATED SYSTEMS

INSTRUMENT CLUSTER &

WARNING LAMPS

MT	Z-44
EC-AT Z-44	, Z-48
SELECTOR INDICATOR LAMPS	. Z-48

BODY-RELATED SYSTEMS

WINDSHIELD WIPER & WASHER	Z-5	0
REAR WIPER & WASHER	Z-5	2
HEADLIGHT CLEANER	Z-54	4
HORNS	Z-6	6
KEY INTERLOCK SYSTEM	Z-70	Б
REAR WINDOW DEFROSTER	Z-70	В
CENTRAL PROCESSING UNIT (CPU)	Z-90	D
THEFT-DETERRENT		
CONTROL SYSTEM	Z-90	D
POWER WINDOW	Z-94	\$
POWER DOOR LOCK	Z-96	8
POWER OUTSIDE MIRROR	Z-98	3
SLIDING SUNROOF Z	-100)
CRUISE CONTROL SYSTEM Z	-104	1
AIR BAG SYSTEM Z	-110)

INTERIOR LIGHTING SYSTEMS

ILLUMINATION LAMPS	Z-80
INTERIOR LAMP	Z-82
CARGO COMPARTMENT LAMP	Z-82
INGITION KEY ILLUMINATION	Z-82
GLOVE BOX LAMP	Z-82

EXTERIOR LIGHTING SYSTEMS

RETRACTABLE HEADLIGHT

SYSTEM	Z-56
HEADLIGHTS	Z-56
FRONT FOG LIGHTS	Z-56
DAYTIME RUNNING LIGHT (DRL)	
CONTROL SYSTEM	Z-58
PARKING LIGHTS	Z-60
FRONT SIDE MARKER LIGHTS	Z-60
TAILLIGHTS	Z-60
REAR SIDE MARKER LIGHTS	Z-60
LICENSE PLATE LIGHTS	Z-60
TURN & HAZARD WARNING LIGHTS	
FEDERAL/CALIFORNIA	Z-62
CANADA	Z-64
STOPLIGHTS	Z-66
HIGH-MOUNT STOPLIGHT	Z-66
BACK-UP LIGHTS	Z-66
DOOR KEY ILLUMINATION	Z-82

AIR CONDITIONING-RELATED SYSTEMS

HEATER	Z-68
AIR CONDITIONER	Z-68

ACCESSORIES

CIGARETTE LIGHTER	Z-78
AUDIO SYSTEM TYPE-1	Z-84
AUDIO SYSTEM TYPE-2	
(BOSE ACOUSTIC WAVE®	
MUSIC SYSTEM)	Z-86
POWER ANTENNA	Z-88
OTHERS	
DIAGNOSIS CONNECTOR	Z-112











HARNESS COLOR: FRONT ENGINI DASH DASH

B-1C

Ð

SENSOR B1-45

28

0











WIRING DIAGRAM Z









WIRING DIAGRAM Z





Z-46





























WIRING DIAGRAM Z 4 REAR COMBINATION LIGHT (TAILLIGHT) RH E3-07 (R)-SHORT HARNESS E3-10 E3-09 0 REAR SIDE 12 LIGHT RH E3-11 LICENSE E3-06 PLATE LIGHTS E3-08 REAR COMBINATION LIGHT (TAILLIGHT) REAR SIDE LH MARKER LIGHT LH















WIRING DIAGRAM































No.






WIRING DIAGRAM Z







Y/R Y/L	LG L Y/R * Y/L	8 1./.

















NOTES: THIS IS THE CONNECTOR AS SEEN FROM THE TERMINAL SIDE. ()...EC-AT







WIRING DIAGRAM





No.	CIRCUIT NAME	FUSE	COLOR	No.	CIRCUIT NAME	FUSE	COLOR
0	(REAR WIPER)	10A	R	۲	METER	15A	L
۲	HAZARD	15Å	L	0	WIPER	20A	Y
۲	ROOM	10A	R	0	STOP	20A	Y
۲	ENGINE	15A	L	0	-	-	-
٩	CIGAR	15A	L	0	(SUN ROOF)	15A	L
۲	DOOR LOCK	10A	R	0	FUEL PUMP	20A	Y
Ø	TAIL	15A	L	0	AIR BAG	10A	R
۲	POWER WIND	30A	G	0	-	-	-

Z WIRING DIAGRAM







WIRING DIAGRAM Z

WIRING DIAGRAM Z

PARTS INDEX

PI

PARTS	SECTION	PARTS	SECTION
A A/C RELAY	Z-68	E 1-2 SWITCH	
A/P BELAY	Z-28	FLASHER UNIT	Z-62, 64
ABS CONTROL UNIT	Z-102	FRONT COMBINATION LIGHTS	
ARS WHEEL SPEED SENSORS		FRONT TURN LIGHTS	Z-62, 64
ACOUSTIC WAVE! GUIDE ASSEMBLY		PARKING LIGHTS	7.60
ACTUATOR	Z-104	FRONT FOG LIGHTS	7.58
	Z-110	FRONT FOG LIGHT SWITCH	7.56
ALTERNATOR	7.24 26	FRONT SIDE MARKER LIGHTS	7.60
	7.84 86	EUEL DUMP	7.20
AUDIO UNIT			7 20
P PACK UP LICHTS	7.66		
DACK UP LIGHT SWITCH	7-66	FUEL PUMP RESISTOR	
BACK-OF LIGHT SWITCH	7.68	FUEL TANK UNIT	
BLOWER MOTOR	7.68	FUEL THERMOSENSOR	
BLOWER MOTOR RELAT	7.48	the second s	-
BRAKE FLUID LEVEL SENSOR	7.104	G GLOVE BOX LAMP	Z-82
BRAKE SWITCH		GLOVE BOX LAMP SWITCH	Z-82
C CARGO COMPARTMENT LAMP	Z-82	HAZARD WARNING SWITCH	Z-62, 64
CARGO COMPARTMENT LAMP SWITCH	7.62	HEADLIGHT CLEANER MOTOR AND RE	LAY Z-54
CENTER SPEAKER	2-84, 86	HEADLIGHT CLEANER SWITCH	Z-54
CENTER SPEAKER AMPLIFIER	Z-84, 86	HEADLIGHT RELAY	Z-56
CIGARETTE LIGHTER		HEADLIGHTS.	Z-56
CIRCUIT OPENING RELAY	Z·28	HEAT HAZARD SENSOR	Z-30
CLUTCH SWITCH	Z-34	HEAT WARNING	Z-44
COMBINATION SWITCH		HEATER CONTROL LINIT	7-68
LIGHT AND DIMMER SWITCH	Z-56	HICH HOUNT STOPI IGHT	7.66
REAR WASHER SWITCH	Z-52	HIGH-MOUNT STOPLIGHT	7.70
REAR WIPER SWITCH	Z-52	HOLD SWITCH	2.00
TURN SWITCH	Z-62, 64	HOOD SWITCH	7.00
WASHER SWITCH	Z-50	HORNS	
WIPER SWITCH	Z-50	HORN RELAY	
CONDENSER	Z-28	HORN SWITCHES	Z-66
COOLANT LEVEL SENSOR	Z-44	HYDRAULIC UNIT	Z·102
COOLING FAN MOTORS	Z-42		
COOLING FAN RELAYS		IGNITER	Z-28
CPU NO. 1 (IN THE JOINT BOX)	Z-90	IGNITION COILS	Z-28
CPU NO. 2	Z-90	ILLUMINATION LAMPS	
CRANK ANGLE SENSORS		ASH-TRAY	Z-80
CRASH SENSORS	Z-110	AUDIO	Z-80
CRUISE CONTROL MAIN SWITCH	7-104	CIGARETTE LIGHTER	
CRUISE CONTROL SWITCH	7-104	CRUISE CONTROL MAIN SWITCH	Z-80
CRUISE CONTROL UNIT	7-104	EPONT FOG LIGHT SWITCH	Z-80
CHUISE CONTROL ONLY		HEADLIGHT CLEANER SWITCH	7-80
E DIAGNOSIS CONNECTOR	Z-112	HEATED CONTROL UNIT	7-80
DIAGNOSTIC MODULE	Z-110		7.82
DOOR KEY CYLINDER SWITCHES	7.90	INOTRUMENT DANEL	7.90
DOOR KEY ULUMINATION	7.82	INSTRUMENT PANEL	7.00
DOOR LOCK ACTUATOR	7.96	REAR WINDOW DEPHOSTER SWITCH	
DOOR LOOK ACTORIOR	7 06	RETRACTABLE HEADLIGHT SWITCH	
DOOR LOCK SWITCH LH	7.00	SELECTOR	
DOOR LOCK SWITCH HH	7.06	INHIBITOR SWITCH	
DOOR LOCK TIMER UNIT	7.00	INJECTORS	Z-30
DOOR OUTER HANDLE SWITCH LH	2.90	INSTRUMENT CLUSTER	Z-44, 46, 48
DOOR SPEAKERS		INTAKE ACTUATOR	Z-68
DOOR SPEAKER/AMP MODULES	Z-86	INTAKE AIR TEMPERATURE SENSOR	Z-3
DOOR SWITCHES		INTERIOR LAMP	Z-82
DRL CONTROL UNIT	Z-58		
DROPPING RESISTOR	Z-70	KEY INTERLOCK RESISTOR	Z-76
		KEY INTERLOCK SOLENOID	
EC-AT CONTROL UNIT	Z-70	KEY REMINDER SWITCH	Z-90
ECU Z-28	, 30, 32, 34	KNOCK SENSOR	7.3
ECI MAIN DELAY	Z-28	RIVOR DENOVI	and a second second second
EGR SWITCH	Z-32		7.8/

18

Z WIRING DIAGRAM

PARTS INDEX

PARTS	SECTION	PARTS	SECTION
M MAGNETIC CLUTCH	Z-68	SWITCH	Z-30
MAGNETIC CLUTCH (A/P)		TURBO CONTROL 1	
METERING OIL PUMP	Z-32	TURBO CONTROL 2	
MIX ACTUATOR	Z-68	TURBO PRE CONTROL	
MODE ACTUATOR	7.68	WASTEGATE CONTROL	7-32
		SPEED SENSOR 1	7.70
THE MELITRAL SWITCH	7.94	SPEED OLIGON TIM	7.44
ALCIARE SHITCH		STADTED	7.94 96
E OU LEVEL SENEOR	7.44	STARTER CUT DELAY	7.04 08
OUL LEVEL SENSOR		STARTER GUT RELAT	7.01
OIL PRESSURE SENSOR		STARTER INTERLOOK SWITCH	7.00
OPTION SWITCH		STOPLIGHT SWITCH	
OXYGEN SENSOR		SUNROOF MOTOH	
		SUNROOF RELAY	Z-100
P/S SWITCH	<u>Z</u> -30	SUNROOF SWITCH	Z·100
PANEL LAMP CONTROL SWITCH	Z-80		and the second second
PARKING BRAKE SWITCH	Z-46	THERMOSWITCH	Z-68
POWER ANTENNA ASSEMBLY	Z-88	THROTTLE SENSOR	Z-32
POWER OUTSIDE MIRROR MOTORS	Z-98	TNS RELAY	Z-60
POWER OUTSIDE MIRROR SWITCH	Z-98		
POWER WINDOW MAIN SWITCH		W WASHER MOTOR	Z-50
POWER WINDOW REGULATORS	Z-94	WATER THERMOSENSOR	Z-32
POWER WINDOW SUB-SWITCH	Z-94	WATER THERMOSENSOR (METER)	
PRESSURE SENSOR		WATER THERMOSWITCH	Z-42, 70
PULSE GENERATOR		WIPER MOTOR	Z-50
REAR COMBINATION LIGHTS REAR TURN LIGHTS STOPLIGHTS TAILLIGHTS REAR HATCH LOCK KEY CYLINDER S REAR SIDE MARKER LIGHTS REAR SPEAKERS REAR SPEAKERS REAR WASHER MOTOR REAR WINDOW DEFROSTER REAR WINDOW DEFROSTER RELAY REAR WINDOW DEFROSTER SWITCH REAR WIPER MOTOR REFRIGERANT PRESSURE SWITCH REFRIGERANT PRESSURE SWITCH RESISTOR ASSEMBLY RETRACTABLE HEADLIGHT ACTUATO RETRACTABLE HEADLIGHT RELAY	Z-62, 64 Z-66 Z-60 WITCH Z-90 Z-60 Z-60 Z-60 Z-52 Z-78 Z-78 Z-78 Z-78 Z-78 Z-78 Z-78 Z-78		
SEAT BELT BUCKLE SWITCH SECURITY LAMP SHIFT-LOCK CONTROL UNIT SOLENOID VALVES AWS CHARGE CONTROL CHARGE RELIEF DOUBLE THROTTLE CONTROL EC-AT EGR ISC PORT AIR BYPASS PURGE CONTROL RELIEF 1 RELIEF 2 SPLIT AIR BYPASS	Z-90 Z-90 Z-76 Z-76 Z-32 Z-32 Z-32 Z-32 Z-32 Z-30 Z-30 Z-30 Z-30 Z-30 Z-30 Z-30 Z-30		

X-00 – Engine Bay Fuse and Relay Box

Purpose: Factory fuse and relay boxes X-01 and X-02 were relocated to this fuse box. Additionally, supporting circuits were added.



- 1. RETRACTOR 30A Fuse. See Z-56 for details
- 2. HEAD 30A Fuse. See Z-56 for details
- 3. #1 30A Radiator Fan Fuse. See Samberg Dual Fan Control diagram for details
- 4. #2 30A Radiator Fan Fuse. See Samberg Dual Fan Control diagram for details
- 5. B1 40A Fuse. Relocated from X-02
- 6. B2 40A Fuse. Relocated from X-01
- 7. BTN 60A Fuse. Relocated from X-02
- 8. ABS 60A Fuse. Relocated from X-02. See Z-102 for details
- 9. Defog 30A #1 Fuse. See Rear Relay Control diagram for details
- 10. Defog 30A #2 Fuse. See Rear Relay Control diagram for details
- 11. Constant 5A 12V Fuse. See 12v Switched Relay and Constant 12V diagram for details
- 12. A/C 25A Fuse. See A/C diagram for details
- 13. Horn 20A Fuse. See Hella Horns diagram for details
- 14. Fuel Pump 20A Fuse. See Rear Relay Control diagram for details
- 15. ABS Fuse 15A. See Z-102 for details

- 16. 12V Switched 25A Fuse. See 12v Switched Relay and Constant 12V diagram for details
- 17. A/C Request Relay. See A/C diagram for details
- 18. A/C Compressor Relay. See A/C diagram for details.
- 19. Retractor Relay. See Z-56 for details
- 20. Headlight Relay. See Z-56 for details
- 21. Horn Relay. See Hella Horns diagram for details
- 22. Fan #1 Relay. See Samberg Dual Fan Control diagram for details
- 23. TNS Relay. See Z-60 for details
- 24. Fan Helper Relay. See Samberg Dual Fan Control diagram for details
- 25. 12V Switched Relay. See 12v Switched Relay and Constant 12V diagram for details
- 26. Fan #2 Relay. See Samberg Dual Fan Control diagram for details
- 27. MAIN 12V battery input to fuse box.
- 28. Aux output for Defog #1 fuse (#9). See Rear Relay Control diagram for details
- 29. Aux output for Defog #2 fuse (#10). See Rear Relay Control diagram for details

Part numbers (mouser.com)

Fuse Box:

Inner Holder – 12146281 Lower Cover – 12146286 Lid(a) – 12162365 Lid(b) – 12160765 Secondary Lock – 12077532 Secondary Lock – 12146283 Seconday Lock – 12146284

Terminals:

800 Series Terminals (for Maxi fuses) - 12110127-L Relays Terminals - 12110844, 12129424 Mini Fuse Terminals – 12110646

Relays

Omron SPDT Micro = 653-G8V-RH-1C7TRDC12 Omron SPST Mini = 653-G8W1A7TRDC12 Omron SPDT Mini = 653-G8W1C7TRDC12

Fuses:

Maxi: 576-0299030.ZXNV - 30A 576-0299040.ZXNV - 40A 576-0299060.ZXNV - 60A Mini: 576-0297010.WXNV - 10A 576-0297015.WXNV - 15A 576-0297020.WXNV - 20A 576-0297025.WXNV - 25A 576-0297030.WXNV - 30A

Location:

X-00 is integrated into the RX7 Front harness







The actual fuse box is located above the driver's front tire in the engine bay.

X-25 – LS1 Harness to Front Harness Connector

Purpose: The fuse / relay box X-00 is located in the RX7 front harness. Power and control of the Fans, A/C, Starter, and Fuel Pump are passed from the front harness to the LS1 harness through this connector.



A: (L) – AC Request from RX7 G-13 (Leads to A/C button). See A/C Diagram for details

B: (Y) – Fan high speed control from LS1 PCM C2 #33. See Samberg Radiator Dual Fan Control diagram for details

C: BLANK

D: (L) – AC Request from LS1 PCM C1 # 17. See A/C Diagram for details

E: (V) – Fan low speed control from LS1 PCM C1 #42. See Samberg Radiator Dual Fan Control diagram for details

- F: (R) From RX7 Starting Circuit to LS1 Starter. See Z-24 for details
- G: (G) 12v Switched for LS1 PCM. See 12V Switched relay and Constant 12v diagram for details.
- H: (L) LS1 PCM A/C Control C1 #43. See A/C Diagram for details

I: (V) – Fuel Pump Relay control from LS1 PCM C2 #9. See Rear Relay Control diagram for details. J: BLANK

K: (Y) 12v Constant for LS1 PCM. See 12V Switched relay and Constant 12v diagram for details.

L: (G) – LS1 A/C Compressor input and C2 #18. See A/C Diagram for details.

Part numbers (mouser.com)

Connector – 15326910 Terminals – 15304720

Mating Connector – 15326915 Terminals - 15304732

Location:

X-25 is integrated into the RX7 Front harness and connects to the LS1 harness on the cabin side of the firewall in the passenger kick panel area.











X-26 – LS1 Harness to RX7 Instrument Harness Connector

Purpose: This connection's primary purpose is to pass sensor signals from the speedhut gauge senders integrated into the LS1 engine harness to the instrument harness which leads to the gauges themselves. Namely, the Oil Pressure, Coolant Temp, IAT, and Fuel Pressure sensors. Other responsibilities include passing A/C Requests, Rev switch for backup lights, MIL Light, Tach signal, and 12v switched power.





A: (Y) – Reverse Light Switch from T56 Transmission. See Rev Lights diagram for details B: (W) – Speedhut Fuel Pressure Gauge sender signal wire. Also see Z-05 C: (R) - Speedhut Fuel Pressure Gauge sender 5v wire. Also see Z-05 D: (B) - Speedhut Fuel Pressure Gauge sender GND wire. Also see Z-05 E: (W) - Tach Signal. See Racelogic Traction Control diagram (5a) and Z-05 for details. F: (B) – Speedhut Coolant Temp Gauge sender GND wire. Also see Z-05 G: (R) – Speedhut Intake Temp Gauge sender 5v wire. Also see Z-05 H: (Y) – 12V Switched. See 12V Switched relay and Constant 12v diagram for details. I: (P) - AC Request from RX7 G-13 (Leads to A/C button). See A/C Diagram for details J: (B) – Speedhut Oil Pressure Gauge sender GND wire. Also see Z-05 K: (R) – Speedhut Oil Pressure Gauge sender 5v wire. Also see Z-05 L: (W) – Speedhut Oil Pressure Gauge sender signal wire. Also see Z-05 M: (B/W) – LS1 PCM MIL light to Check Engine Light wire. See MIL Light diagram for details. N: (W) – Speedhut Coolant Temp Gauge sender signal wire. Also see Z-05 O: (Y) – Speedhut Intake Temp Gauge sender signal wire. Also see Z-05 P: (Y) – Reverse Light Switch from T56 Transmission. See Rev Lights diagram for details

Delphi Packard Part numbers Connector = 15326085 Secondary Lock = 15326059 Male Pins = 15326268

Mating Connector = 15326084 Secondary Lock = 15326059 Female Pins = 12191818

Location:

Z-02 is integrated into the LS1 engine harness and the RX7 instrument harness







X-27 – LS1 Harness Injector Breakout for TC.

Purpose: This connector is strictly a break in the injector signals from the LS1 PCM. The purpose is to give access to the Racelogic Traction Control computer which needs these signals. Its secondary purpose is to provide a way to quickly disconnect the Racelogic system and jumper the connector with the terminator plug (see below) which disables traction control and restores the factory connection between the LS1 PCM and injectors.



A: (DL/W) - To Injector #8 through the LS1 Harness. See Racelogic Traction Control Diagram for details B: (B/W) – To Injector # 5 through the LS1 Harness. See Racelogic Traction Control Diagram for details C: (Y/B) – To Injector #6 through the LS1 Harness. See Racelogic Traction Control Diagram for details D: (B) – To Injector #1 through the LS1 Harness. See Racelogic Traction Control Diagram for details E: (L/B) – To Injector #4 through the LS1 Harness. See Racelogic Traction Control Diagram for details F: (R/B) – To Injector #7 through the LS1 Harness. See Racelogic Traction Control Diagram for details G: (LG/B) – To Injector #2 through the LS1 Harness. See Racelogic Traction Control Diagram for details H: (P/B) – To Injector #3 through the LS1 Harness. See Racelogic Traction Control Diagram for details I: (DL/W) – To PCM C1 #77 through LS1 Harness. See Racelogic Traction Control Diagram for details J: (B/W) – To PCM C1 #76 through LS1 Harness. See Racelogic Traction Control Diagram for details K: (Y/B) – To PCM C1 #37 through LS1 Harness. See Racelogic Traction Control Diagram for details L: (B) – To PCM C1 #36 through LS1 Harness. See Racelogic Traction Control Diagram for details M: (L/B) – To PCM C1 #44 through LS1 Harness. See Racelogic Traction Control Diagram for details N: (R/B) – To PCM C1 #43 through LS1 Harness. See Racelogic Traction Control Diagram for details O: (LG/B) – To PCM C1 #4 through LS1 Harness. See Racelogic Traction Control Diagram for details P: (P/B) – To PCM C1 #3 through LS1 Harness. See Racelogic Traction Control Diagram for details

Part numbers (mouser.com)

Connector –15326667 Terminals – 15304720

Mating Connector –15326666 Terminals - 15326915

Location:

X-27 is integrated into the LS1 Engine Harness and is accessible in the passenger side rear bin / battery compartment.






Z-02 – Dash Top Gauge Connector

Description: Z-02 is a quick disconnect between the instrument harness and the gauges mounted on top of the dash.





A: (L) – Illumination Ground. See page Z-80

B: - BLANK

C: (Y) – Thermocouple (Intake Temp sensor) GND. Wired to X-26 (LS1 engine harness) then to sensor.

D: (R) – Thermocouple (Intake Temp sensor) SIGNAL. Wired to X-26 (LS1 engine harness) then to sensor. E: - BLANK

F: (B/Y) – Switched 12V. Fused through JB-02 at the 15A METER fuse.

G: - BLANK

H: (L) – Wideband signal. This is wired through the instrument harness and connects through a single pin connector close to X-26 to the Floor Harness, where it is carried to just behind the passenger door to Z-03 which connects directly to the AEM UEGO wideband controller located in the passenger bin / battery compartment.

. I: (B) – Ground

J: - BLANK

K: - BLANK

L: (R) – Fuel Pressure Sensor 5V. Wired to X-26 (LS1 engine harness) then to sensor.

M: (W) - Fuel Pressure Sensor SIGNAL. Wired to X-26 (LS1 engine harness) then to sensor.

N: (B) - Fuel Pressure Sensor GND. Wired to X-26 (LS1 engine harness) then to sensor.

O: - BLANK

P: (Y) – Illumination 12V. See page Z-80

Delphi Packard Part numbers Connector = 15326085 Secondary Lock = 15326059 Male Pins = 15326268

Mating Connector = 15326084 Secondary Lock = 15326059 Female Pins = 12191818

Location: Z-02 is integrated into the RX7 instrument harness



The actual connector is located near the center speaker pod on the top of the dash.





Z-03 – Wide Band Connector

Description: Z-03 is a quick disconnect between the AEM UEGO Wideband controller and the Floor Harness.



A: - BLANK

B: - BLANK

C: (W) – Wideband output to HPTuners EIO interface

D: (W) – Wideband output to dash top speedhut gauge. This is wired through the Floor Harness and connects through a single pin connector close to X-26 to the Instrument Harness, where it is carried to to the top of the dash to Z-02 which is the connector for the dash top speedhut gauges.

E: (G) – 12V Switched. This is fused and powered by the Rear 12v Switched network. See **Rear 12v** Switched Network documentation for more info.

F: - BLANK

G: (B) – Ground

Delphi Packard Part numbers Connector = 12059472 Secondary Lock = 12052199 Female Pins = 12052139, 12084200

Mating Connector = 12052200-B Secondary Lock = 12052199 Male Pins = 12033820, 12077628 Location:

Z-03 is integrated into the RX7 Floor Harness



The actual connector is located inside the rear passenger bin / battery compartment.





Z-04 – Head Unit Connector

Description: Z-04 is a connector for future head unit installs. It provides the bare minimum wiring to power an aftermarket headunit.



A: (L/B) – 12V Switched supply. Fused through JB-02 at the 15A CIGAR fuse. See page Z-86 B: (R/B) – Illumination 12V. Fused through JB-07 at 15A TAIL fuse See pages Z-80 and Z-60 C: (R/G) – Illumination Ground. See page Z-80 D: (L/R) – 12V Constant supply. Fused through JB-02 at the 10A ROOM fuse. See page Z-86

Delphi Packard Part numbers Connector = 12162102 Secondary Lock = 12047948 Male Pins = 12077628

Mating Connector = 12162144 Secondary Lock = 12047948 Female Pins = 12084200

Location: Z-04 is integrated into the RX7 instrument harness





The actual connector is located near the Head Unit opening in the dash.



Z-05 – Gauge Cluster Connector

Description: Z-05 is a quick disconnect between the gauge cluster and the instrument harness.





A1: (G/B) LH Turn Signal Light + Signal. See Z-46 for details. A2: (G/W) RD Turn Signal Light + Signal. See Z-46 for details. A3: (R/G) Illumination Ground. See Z-80 for details A4: (B/Y) 12V Switched See Z-44 for details. A5: Blank A6: (R) Fuel Level Sensor. See Z-44 for details A7: (R) Coolant Temp Sensor. Also see X-26 A8: (B) Coolant Temp Sensor. Also see X-26 B1: (BR/Y) Brake Light - Signal. See Z-46 for details. B2: (R/W) High Beam Light + Signal. See Z-46 for details. B3: (R/B) Illumination 12v. See Z-80 for details B4: Blank B5: Blank B6: (B) Oil Pressure Sensor. Also see X-26 B7: (R) Oil Pressure Sensor. Also see X-26 B8: (G) Oil Pressure Sensor. Also see X-26 C1: (LG) Seat Belt Light - Signal. See Z-46 for details. C2: (L/R) Speedometer 12v Constant Supply. See Z-86 for details C3: (W) Tach Signal. See Racelogic Traction Control diagram (5a) for details. C4: (B) Ground. C5: Blank C6: (G/O) ABS Light - Signal. See Z-46 for details. C7: (B/W) MIL Light – Signal. Also see X-26

C8: (Y) Defrost Light – Signal. See Z-46 for details.

Delphi Packard Part numbers Connector = 15336173 Lock = 15355357 Lock = 15373421 Terminals = 15326269, 15304732

Mating Connector = 15366099 Lever = 13869381 Lock = 15355359 Lock = 15373422 Terminals = 13528779, 12191819

Location:

Z-05 is integrated into the RX7 instrument harness



The actual connector is located behind the gauge cluster:







Z-06 – Racelogic Traction Control Digital Adjuster

Description: Z-06 is a quick disconnect between the Racelogic Traction Control Main unit and its Digital Adjuster.



- A: (R) To Racelogic TC B5 DIAG TX. See Racelogic Traction Control diagram for details
- B: (L) To Racelogic TC B6 DIAG RX. See Racelogic Traction Control diagram for details
- C: (G) To Racelogic TC B7 GND. See Racelogic Traction Control diagram for details
- D: (Y) To Racelogic TC B15 12v. See Racelogic Traction Control diagram for details
- E: (R) To 15A Meter Fuse for 12V Switched power. See Racelogic Traction Control diagram for details
- F: (L) To Racelogic TC A16 GND. See Racelogic Traction Control diagram for details
- G: (G) To Racelogic TC A3 POT. See Racelogic Traction Control diagram for details
- H: (Y) To Racelogic TC B14 GSHIFT. See Racelogic Traction Control diagram for details

Part numbers (mouser.com)

Connector – 15326655 Terminals – 15304720 Mating Connector – 15326654 Terminals - 15326915

Location:

Z-06 is integrated into the RX7's rear harness



The actual connector is located behind the driver's side kick panel







Z-07 & Z-08 – Cruise Control Signal Extension

Description: Z-07 is a connector that pulls signals straight from the LS1 PCM connectors. The signals are then routed through the RX7's floor harness to the passenger kick panel area and terminate through Z-08. Z-08 is made to connect to Z-09. The idea being that these signals could be transmitted to the front harness axillary extension made up of Z-09 and Z-10 so the PCM signals can be routed from Z-09 and the switch signals can be routed from Z-10 to a Camaro cruise control module located somewhere along the front harness path. See document for Z-09 and Z-10 for additional information.





- A: (P) LS1 PCM C1 # 32 Clutch Pedal Position Switch Signal.
- B: (W) LS1 PCM C2 # 50 Vehicle Speed Sensor Signal.
- C: (B) LS1 PCM C2 # 37 Cruise Control Inhibit.
- D: (R) LS1 PCM C2 # 13 Cruise Control Enable Signal

Delphi Packard Part Numbers:

Connector = 12186568 Secondary Lock = 12047948 Female Pins = 12084200

Mating Connector = 12186271 Secondary Lock = 12047948 Male Pins = 12045773

Location:

Z-07 and Z-08 are integrated into the RX7's floor harness



Z-07 is located in the passenger rear bin / battery compartment. Z-08 is located in the passenger kick panel.



Z-09 & Z-10 – Front Harness Aux Wiring

Description: Z-09 and Z-10 are simply an auxiliary wiring loop that runs within the front harness that allows 4 wires to be available to run from the passenger's side kick panel to the driver's side kick panel and vice versa. At the time of this document, this connection is NOT being used at all. Future plans may involve the use of this harness. Specifically, the addition of a Camaro cruise control. The idea being that these signals could be transmitted to the front harness axillary extension made up of Z-09 and Z-10 from Z-07 and Z-08 so the PCM signals can be routed from Z-09 and the switch signals can be routed from Z-10 to a Camaro cruise control module located somewhere along the front harness path. See document for Z-07 and Z-8 for additional information.



A: (L) Connects Z-09 and Z-10's A terminal B: (Y) Connects Z-09 and Z-10's B terminal C: (L) Connects Z-09 and Z-10's C terminal D: (P) Connects Z-09 and Z-10's D terminal

Delphi Packard Part Numbers:

Connector = 12186271 Secondary Lock = 12047948 Female Pins = 12045773

Mating Connector = 12186568 Secondary Lock = 12047948 Male Pins = 12084200

Location: Z-09 and Z-10 are integrated into the RX7's front harness



Z-09 is located in the passenger's kick panel. Z-10 is located in the driver's kick panel.



Z-11 – Battery Connection for Rear 12V Switched Relay

Description: Z-11 is a connector that takes power and ground straight from the battery and delivers it to the 12V Switched rear relay. See the Power Distribution (Rear) diagram for details.



A: (B) Connects directly to Battery Ground B: (R/W) Connects to external 30A blade fuse then to Positive Battery Terminal

Delphi Packard Part Numbers:

Connector = 12065863 Secondary Lock = 12059897 Male Pins = 12052172-L

Mating Connector = 12052613 Secondary Lock = 12059897 Female Pins = 12052139-L

Location:

Z-11 is integrated into the RX7's floor harness



Z-11 is located in the passenger's side rear bin / battery compartment.





Z-12 – Fuel Pump Power Connection

Description: Z-12 is the last connector in the chain to supply power to the external Bosch 044 fuel pump. See Rear Relay Control diagram for more details.



A: (R) Connects directly to Bosch 044's + stud. See Rear Relay Control diagram for more details.

Delphi Packard Part Numbers:

Connector = 12015952 Female Pins = 12052139-L

Mating Connector = 12015987 Male Pins = 12052172-L

Location:

Z-12 is integrated into the RX7's rear harness



Z-12 is located on the driver's side of the rear cargo bay.





Z-13 – Fuel Level Sensor Connector

Description: Z-13 connects the rear harness directly to the fuel level sensor. See Z-44 for more details.



A: (L) Connects to the ground side of the RX7's Fuel Level Sensor. See Z-44 for more details. B: (W/G) Connects to the signal side of the RX7's Fuel Level Sensor. See Z-44 for more details.

Delphi Packard Part Numbers:

Connector = 12052641 Secondary Lock = 12052634 Female Pins = 12048074

Mating Connector = 12162000 Secondary Lock = 12052634 Male Pins = 12045773

Location:

Z-13 is integrated into the RX7's rear harness



Z-13 is located on the driver's side of the rear cargo bay.





Driver's Door Lock Actuator:

Purpose: The FD3 RX7 was built with only 1 lock actuator located in the passenger's door. In order to add remote unlock/lock capabilities to the RX7 via an aftermarket alarm it was necessary to add a lock actuator in the driver's door and a new dual relay control system. See page Z-97 for a full diagram.

Part Numbers:

Relay Sockets = SRS105 Tyco Relays = 1432791-1 Actuator = 524N

Location:

K2-01 located at the top of the driver's door. Also shown are modifications according to the diagram on page Z-97



Location of two relays used to actuate both door's actuators. Located near the driver's side kick panel:



Location of the new actuator in the driver's side door.



Rear Relay Box

Purpose: This auxiliary relay box houses relays for the fuel pump, trunk popper, and rear defroster.



A: Rear Defroster Relay #1. See Rear Relay Control Diagram for details

- B: Rear Defroster Relay #2. See Rear Relay Control Diagram for details
- C: Trunk Popper Relay. See Rear Relay Control Diagram for details
- D: Fuel Pump Relay. See Rear Relay Control Diagram for details

Part Numbers:

Hella 4 Relay Enclosure Kit = H84988001 Tyco Relays = 1432791-1

Location:

The rear relay box integrated into the RX7's rear harness and is located underneath the driver's side rear bin.





The actual connector is located under the driver's side rear bin.


LS1 Engine Harness Mod Notes

The LS1 engine harness and PCM used in my car originally came out of a 99 firebird with an automatic transmission. I purchased the FD chasses after the harness had already been modified by Hinson Supercars. I performed extensive modifications to the harness myself and have documented Hinson's changes along with my own below:

- Two connectors were added to the harness located at the firewall on the inner cabin section of the harness. Those two connectors are called X-25 and X-26 and have their own documentation.
- The harness received a ~5ft extension to relocate the PCM to the passenger side rear bin / battery compartment.
- Rear O2 Sensors were deleted
- Automatic Transmission connectors were deleted and PCM was flashed for a manual transmission application.
- Skip Shift / CAGS connector = Deleted.
- VATS = Deleted
- Deleted Alternator Excite wiring. Added Self Exciting Regulator to Alternator
- Extended O2 wire harnesses for longtube headers.
- Relocated OBD2 Connector to the passenger side rear bin / battery compartment.
- Integrated X-27 into the harness for Racelogic Traction Control. See X-27 documentation for more details.

- Added Z-07 to facilitate the breakout of cruise control signals. See Z-07 documentation for details.
- Integrated Speedhut gauge sensor wiring. See X-26 and Z-05 documents for more details.
- Wrapped harness in nylon sleeving. Wrapped sections that will be exposed to heat in fiberglass / aluminum heat shielding.
- Labeled all connectors
- Tailored wire lengths to the LS1 RX7 engine bay.

Fbody Specific Connector Mods:

C-100 – Black 10 pin connector

- A- Pink (Bank 1 Ignition/Injector switched power in). <u>Relocated to X-25 Switched 12V. See X-25</u> <u>documentation for more details</u>
- G- Pink (Transmission/EVAP switched power in) <u>Relocated to X-25 Switched 12V. See X-25</u> <u>documentation for more details.</u>
- J- Dark Green (Low Speed relay control output from PCM). <u>Relocated to X-25. See X-25</u> <u>documentation for more details.</u>

C101 - Gray 10 pin connector.

- B Pink (Bank 2 Ignition/Injection switched power in). <u>Relocated to X-25 Switched 12V. See</u> X-25 documentation for more details.
- D Dark Green / White (Fuel Pump Relay Control Output from PCM). <u>Relocated to X-25. See</u> <u>X-25 documentation for details.</u>
- E Pink / Black (Switched 12v power for PCM). <u>Relocated to X-25 Switched 12V. See</u> X-25 documentation for more details.
- G Orange (Constant power for PCM). Relocated to X-25 Constant 12V. See X-25 documentation for details.
- H Black / White (Ground). Grounded at battery.

C102

A - Purple (From Starter Solenoid). <u>Relocated to X-25. See documentation for X-25 for more</u> <u>details.</u>

C105 - black 8 pin connector.

B - Pink (Transmission / Stop lamp / Heated O2s /MAF switched power). <u>Relocated to X-25 –</u> <u>Constant 12V. See X-25 documentation for more details</u> G - White (Tach Signal from PCM). Relocated to X-26. See X-26 documentation for details.

C220 - Natural color 10 pin connector.

- E- Black / White (Ground). Grounded at battery.
- G- Brown (Back-up lite switch input). Relocated to X-26. See X-26 documentation for details.
- H- Light green (Back-up lite switch output). <u>Relocated to X-26. See X-26 documentation for</u> <u>details.</u>
- K- Dark Green / White (VSS Signal). <u>Relocated to Z-07. See Z-07 documentation for details.</u>

C230 - Blue 10 pin connector.

B- Brown / White (MIL light). <u>Relocated to X-26. See X-26 documentation for details.</u>

LS1 Engine Harness Connector Pinouts:

Circuit Number C1 (Blue)

This table contains all of the Pin connections, Wire colors, and Functions of Connector C1 (Blue). There are 80 pins on this connector

Pin	Wire Color	Function
1	BLK	PCM GROUND
2	LT GRN	CRANK. POS. SENSOR B+ SUPPLY
3	PNK/BLK	INJECTOR 3 CONTROL
4	LT GRN/BLK	INJECTOR 2 CONTROL
5	-	NOT USED
6	-	NOT USED
7	-	NOT USED
8	GRA	TP SENSOR 5V REF
9	-	NOT USED
10	-	NOT USED
11	LT BLU	KNOCK SENSOR REAR
12	DK BLU/WHT	CRANKSHAFT POS. SIGNAL
13	-	NOT USED
-14	-	NOT USED
$\frac{15}{15}$	-	NOT USED
16	-	NOT USED
17	DK BLU	TRANS. RANGE SIGNAL B
18	RED	TRANS. RANGE SIGNAL C
19	PNK	IGNITION. POS. VOLT.
20	ORG	BAT. POS. VOLT
21	YEL/BLK	CRANK POS. REF. LOW
<u>22</u>	-	NOT USED
23	GRA	FUEL TANK PRESSURE SENSOR /FUEL TANK SENDER GROUND
24	-	NOT USED
$\frac{25}{25}$	TAN	HO2S SIGNAL LOW BANK 2 SENSOR 2
26	TAN	HO2S SIGNAL LOW BANK 2 SENSOR 1
$\frac{27}{27}$	-	NOT USED
28	TAN/WHT	HO2S SIGNAL LOW BANK 1 SENSOR 2
29	TAN/WHT	HO2S SIGNAL LOW BANK 1 SENSOR 1

30	-	NOT USED
31	-	NOT USED
32	GRY	CLUTCH PEDAL POSITION. SWITCH SIGNAL
33	PPL	TCC BRAKE SWITCH
34	ORN/BLK	PNP SWITCH SIGNAL
35	-	NOT USED
36	BLK	INJECTOR 1 CONTOL
37	YEL/BLK	INJECTOR 6 CONTROL
38	-	NOT USED
39	-	NOT USED
40	BLK	PCM GROUND
41	BLK	EGR PINTLE POSITION, SENSOR GROUND
42	DK GRN	ENG. COOLING FAN RELAY 1 CONTROL
43	RED/BLK	INJECTOR 7 CONTROL
44	LT BLU/BLK	INJECTOR 4 CONTROL
45	GRA	A/C REFRIG PRESS SENSOR 5V REF
46	GRA	FUEL TANK PRESS. SENSOR 5V REF
47	GRA	FGR PINTLE POS SENSOR 5V REF
48	GRA	MAP SENSOR 5V REF
49	_	NOT USED
50	_	NOT USED
51	DK BLU	KNOCK SENSOR SIGNAL FRONT
52	-	NOT USED
53	RLK	TRAN TEMP SENSOR GROUND
54	ORG/BLK	MAP SENSOR GROUND
55	BRN	EGR PINTLE POSITION SENSOR SIGNAL
56	_	
57	ORG	BAT POS VOLT
58	DRK GRN	SERIAL DATA
59	-	NOT USED
60	BLK	TP SENSOR GROUND
61	PNK/BLK	CAMSHAFT POS SENSOR REF LOW
62	-	NOT USED
63	_	NOT USED
64	_	NOT USED
65	ppi.	HO2S SIGNAL HIGH BANK 2SENSOR2
66	PPL	HO2S SIGNAL HIGH BANK 2 SENSOR 1
67	-	NOT USED
68	PPL/WHT	HO2S SIGNAL HIGH BANK1 SENSOR 2
69	PPL/WHT	HO2S SIGNAL HIGH BANK I SENSOR 1
70	BRN	LOW OIL LEVEL SWITCH
71	_	NOT USED
72		NOTUSED
73	BRN/WHT	CAMSHAFT POS_SENSOR SIGNAL
74	VEL	ENG. COOLLANT TEMP SENSOR SIGNAL
75	-	NOT LISED
76	BLK/WHT	INJECTOR 5 CONTROL
77	DK BLU/WHT	INJECTOR 8 CONTROL
78	_	NOT USED
79	GRA OR WHT	SKIP SHIFT SELENOID CNTROL (M/T) OR 2&3 SHIFT SELENOID CONTROL (A/T)
80	BLK	ENG COLOLANT TEMP SENSOR GROUND
00		

Circuit Number C2 (Red)

This table contains all of the 1999 Pin connections, Wire colors, and Functions of Connector C2 (Red). There are 80 pins on this connector

Pin	Wire Color	Function
1	BLK	PCM GROUND
2	BRN	TCC CONTROL SOLENOID
글	-	NOT USED
4	PPL	AIR SELENOID CONTROL
5	-	NOT USED
6	RED/BLK	TRANS. PRESS.CONTROL SELENOID CONTROL HIGH
7	RED	EGR CONTROL
8	LT BLU/WHT	TRANS. PRESS.CONTROL SELENOID CONTROL LOW
9	DK/GRN	FUEL PUMP RELAY CONTROL
10	WHT	ENG. SPEED (TACH) OUTPUT SIGNAL
11	-	NOT USED
12	-	NOT USED
13	WHT	CRUISE CONTROL ENABLE SIGNAL
14	RED/BLK	A/C REFRIG. PRESS. SENSOR SIGNAL
15	RED	ALTERNATOR TERMINAL
16	-	NOT USED
17	DRK GRN/WHT	A/C REQUEST SIGNAL
18	DK GRN	A/C STATUS SIGNAL
19	-	NOT USED
20	LT GRN/BLK	VSS REFERENCE LOW
21	PPL/WHT	
22	-	NOT USED
23	-	NOT USED
24	DK BLU	TP SENSOR SIGNAL
25	TAN	IAT SENSOR SIGNAL
26	PPL	INGNITION CONTROL 1
27	RED	INGNITION CONTROL 7
28	LT BLU/WHT	INGNITION CONTROL 6
29	DK GRN/WHT	INGNITION CONTROL 4
30	DK BLU	VDT FUEL ENABLE SIGNAL
31	YEL	MAF SENSOR SIGNAL
32	LT GRN	MAP SENSOR SIGNAL
33	DK BLU	ENG. COOLING FAN RELAY 2 & 3 CONTROL
34	DK GRN/WHT	EVAP PURGE CANISTER VALVE CONTROL
35	-	NOT USED
36	BRN	AIR PUMP RELAY CONTROL
37	DK GRN	CRUISE CONTROL INHIBIT
38	-	NOT USED
39	RED	CAMSHAFT POS. SENSOR B+ SUPPLY
40	BLK	PCM GROUND

Continued on next page

Circuit Number C2 (Red)

Table continued.

Pin	Wire Color	Function
41	GRA	EGR POSITION SENSOR GROUND
42	TAN/BLK	TCC ENABLE CIRCUIT
43	DK GRN/WHT	A/C CLUTCH RELAY CONTROL
44	LT GRN	REV. INHIBIT SOLENOID CONTROL
45	WHT	EVAP CANISTER VENT VALVE CONTROL
46	BRN/WHT	MALFUNCTION INDICATOR LAMP CONTROL
47	YEL/BLK	TRANMISSION. SHIFT SOLENOID B
48	LT GRN	TRANMISSION. SHIFT SOLENOID A
49	-	NOT USED
50	DK GRN/WHT	VEHICLE SPEED OUTPUT CIRCUIT
$\frac{51}{51}$	YEL/BLK	TRANS. TEMP. SENSOR SIGNAL
$\frac{52}{5}$	-	NOT USED
53	GRA/BLK	SPARK RETARD SIGNAL
54	PPL	FUEL LEVEL SENSOR SIGNAL
$\overline{55}$	-	NOT USED
$\frac{56}{56}$	-	NOT USED
57	PPL	IAT SENSOR GROUND
58	-	NOT USED
59	-	NOT USED
60	BRN	INGNITION CONTROL REFERENCE LOW BANK 1
61	BRN/WHT	INGNITION CONTROL REFERENCE LOW BANK 2
<u>62</u>	-	NOT USED
63	PNK	TRANS RANGE SIGNAL A
6 4	DK GRN	FUEL TANK PRESSURE SENSOR SIGNAL
65	-	NOT USED
66	PPL/WHT	IGNITION CONTROL 8
67	RED/WHT	IGNITION CONTROL 2
68	DK GRN	IGNITION CONTROL 5
69	LT BLU	IGNITION CONTROL 3
70	-	NOT USED
71	-	NOT USED
72	-	NOT USED
73	-	NOT USED
74	-	NOT USED
75	-	NOT USED
76	LT GRN/WHT	IAC COIL B HIGH
77	LT GRN/BLK	IAC COIL B LOW
78	LT BLU/BLK	IAC COIL A LOW
79	LT BLU/WHT	IAC COIL A HIGH
80	-	NOT USED



Done light avea aux connector output for very circuits: Racelegic traction coutrol Wounted above the very prosences 12 1 Switched power Relay located in very cargo bay. Wide bund controller (ter) Rew 120 Switched 27 87a 86 Power D: Stribution (Rent) R CN/Q) 200-03] is kneder (13) Q X-03 (B) [2-11] (2)) 400 30 Amp Rev Kely yok sus [20-06] Aut of my (RAW) 13/6) Halfspee FD3 OIGZ Tear 0 1X-03 Q 0/m 1.0 F Bettory + 14















NOSNOS RO Cuick disconnect AFM Inline UFGO Controller EIO Speed hut Hp tuners controller diagram Gewye 11 FUDUT 0 Int (1) 20-2 8 62 B S 3 3 1 Wideburd [50-2]-浓水水水 Rich disconnect by (Keen) gistripation Even 151 years Suitched (w) (45 FUS Hulfspee 11.



Receivaic TC X-25 U , ve 21/ces A-1 A-14 (011W) 年2 splices B (6Y/L) Indectors (R/B) + + 4 B-9 treped in to (G/R) 井の Y/W J've B-8 1 No-07 #2 (P/3) B/W) K/V 12/132 22 (6) Gy/3) 44 A-7 2.5 Kes Kisht to (6/3) (P/B) N Ø # -24 2 ×13) (1613) 11 A-13 A (0/3) BJ A-12 # 3 4 hot serviced (8/3) A-11 10-017 (re) (Y) (02/w) C1 世77 A-6 F Dissieur Reer Left OR B-2 (R/B) S B autrouts C1 #43 (w/R) 3-1 (Y13) 1 L1位37 P A-21 MOT Severe (151W) 3 (64) (1世76 Con tral A-22 Injec X-23 CI-X 10-05 K (1/3) (1) Z Front Right (1 #44 (6) A-5 -23 R (Y)(P/B) pour > (1#3 NECTION -10 (1613) (0)C1#4 2 9 1 t-speed into not-Severed (R) 5 (3) C1#36 8 [HU-0] 21-XX 3 (R) scelopic A-4 Front Left To do unt + 24 XX-06 d-X (1/0, 7-26 0 10/7 (w/3) X-260 Stutus LED A-18 (6) 0 A-3 from power distribution Control Distal 121 Switched output H (1/3) (L)L Scheung 1 A-16 (rear) diabran 3 (m) -1 VI (4) M215h5 0 -15 COLUNISA METER F0 B PINE (Y) Speed # 3-14 PCW RPIM S: Swill Hulfspec (6) 1 4464000 Adjuster C2 #10 ABS 90-(1) 0 Juckl Tonition 45 121 From 0 N (R) 41 JAMP Inline fusc B-5 21 21 Ba 272)